

## How to update DS708

### Register the Tool:

Please log in our website to register an Autel ID. Then log in our website with your Autel ID and password to register your DS708.

Your Account > Product Registration

**Your Account**


- Your Devices
- Your Orders
- Redeem
- Product Registration**
- Your Issue
- PC Suite
- Your Messages
- Your Profile
- Reset Password
- Payment Instructions

### Product Registration

Product Model \* MaxiDAS DS708

Serial Number \*

Register Password \*

Code \* 2wm8  [Try a different image](#)

When registering DS708 on our website, please make sure that the serial number and register password that you input are correct.

On DS708, you can press on **Setup/Help->About** to double check the serial number and register password.

### Method 1: Updating via DS708:

After registering DS708 on the website successfully, please connect DS708 to Internet via Ethernet connection or WiFi, and then choose **Update** on the main screen of DS708.

When the **Update** screen loads successfully, you can download all the software updates directly on DS708.

PS: To ensure high Internet speed, Ethernet connection is recommended.

## Method 2: Updating via Computer

If you cannot download the software directly on DS708, please update DS708 via the PC in this way:

1. Log in our website with your Autel ID and password, and then download the latest PC Suite for DS708 from your account.

<http://pro.auteltech.com/>

Your Account > PC Suite Program 0 Cart


Your Account		PC Suite				
Your Devices		Software	Products	Latest Version	Release Date	Language
Your Orders						Operation
Redeem		Autel PC Suite	MaxiCheck AbsSrs \ MaxiCheck DP...	V6.31	12/13/2013	English
Product Registration		PC Suit	Mot Pro	V6.33	12/13/2013	English
Your Issue		Master Pro PC Suit	Master Pro	V6.33	12/13/2013	English
PC Suite		VHC011 PC Suit	VHC011	V6.31	11/15/2013	English
Your Messages		MaxiSYS PC Suite	MaxiSYS \ MaxiSYS Mini \ Max iSYS...	V2.02	11/01/2013	English
Your Profile		PC Suite	MaxiDAS DS708	V6.31	10/30/2013	English
Reset Password						
Payment Instructions						

2. Then please install the PC suite software on a Windows computer **that can get Internet access.**

3. Load the SD card to the computer via a card reader, run the update client software, and then input your Autel ID and password to log in our system.

4. Then wait for the Update window to display. If you forget your password unintentionally, you may always click the [Forget Password?] to link to our website and find your password back.

DS708 Update V6.31



Account: **support@auteltech.com**

Password: **●●●●●●●●**

[Forget Password?](#) [Register](#)

☐ Remember Password

**Login**

5. You can use the pull-down menu on the right to select an SD card if two or more SD cards have been connected to the PC. And you can click on the Install buttons to download the software updates.

To ensure the good performance of the scan tool, it is recommended to download and install all the software updates.

DS708 Update V6.31 (S/N:DS019Q004468)

**Updates** | **Installed Programs**

Select the updates to install from the list below:

Program	Software Kit	Version	Status	Size(MB)
<input checked="" type="checkbox"/> GM	DS708 Softwz	V10.00	Need to Install	64.13
<input type="checkbox"/> FORD	DS708 Softwz	V9.00	Need to Install	167.68
<input type="checkbox"/> LANDROVER	DS708 Softwz	V6.10	Need to Install	23.87
<input type="checkbox"/> AUDI	DS708 Softwz	V7.10	Need to Install	145.90
<input type="checkbox"/> ABARTH	DS708 Softwz	V3.00	Need to Install	61.11
<input type="checkbox"/> ALFA	DS708 Softwz	V3.00	Need to Install	0.00
<input type="checkbox"/> BENZ	DS708 Softwz	V10.00	Need to Install	0.00
<input type="checkbox"/> BMW	DS708 Softwz	V9.40	Need to Install	0.00

**Exit**  
**F:\**  
 Total Size:1883MB  
 Free Size:1852MB  
☐ SelectAll  
**Update Selected Items**  
**Pause**  
**Pg up**  
**Pg dn**

6. After downloading all the software, please insert the SD card back to DS708; then you can enjoy the new software.

[www.autocardiag.com](http://www.autocardiag.com)

E-mail:[autocardiag@gmail.com](mailto:autocardiag@gmail.com)

Skype:Marshall.obd2

Whatsapp:86-13476108995

[www.autocardiag.com](http://www.autocardiag.com)